



## BT025B Fitting Guide

Vehicle: Colorado / D-Max / Rodeo  
Year Model: 2007-onwards  
Product: Auxiliary Battery Box  
Product Code: BT025B

Fits up to N70zz 12 inch case battery or  
up to 120AH size 4x4 battery.

1. Assemble the bottom plate using  
3 x 6mm bolts and place battery  
tray into desired position.

3. Mark and drill the 3 top holes  
and tighten 3 x 4mm bolts into  
place with backing plate behind the  
lip of the tub.



2. Mark holes and drill being careful  
not to drill into the tyre. Then  
tighten 3 x 6mm bolts into place.

4. Sit battery into tray and place  
battery hold down on the top inner  
corner of the battery. Put J hooks  
into the corner holes in the battery  
tray and through the hold down,  
then tighten until battery is firmly  
in place.

**Comes complete with:**  
6 x 6mm bolts  
3 x 4mm bolts  
1 x hold down with J hooks

