

BT025G Fitting Guide

Vehicle: Ford PX Ranger XL & XLS (no tub liner)
Year Model: 2011-onwards
Product: Auxiliary Battery Box
Product Code: BT025G

Fits up to N70zz 12 inch case battery or
up to 120AH size 4x4 battery.

1. Assemble the bottom plate using 3 x 6mm bolts and place battery tray into desired position.

3. Mark and drill the 3 top holes and tighten 3 x 4mm bolts into place with backing plate behind the lip of the tub.



2. Mark holes and drill being careful not to drill into the tyre. Then tighten 3 x 6mm bolts & washers into place.

4. Sit battery into tray and place battery hold down on the top inner corner of the battery. Put J hooks into the corner holes in the battery tray and through the hold down, then tighten until battery is firmly in place.

Comes complete with:
6 x 6mm bolts & nuts
3 x washers
6 x 4mm bolts
1 x hold down with J hooks