

ROADsafe™ 4WD



RP-NAV22 FITMENT GUIDE

Fitted to D22 Navara—

Fitted to factory retained nuts on both L/H & R/H Sides.

Install 12mm Spacer Plates (one per point) to provide clearance on angled chassis gusset.

The tow point mounting holes are slightly elongated to allow tolerance for different Country of Origin re. chassis/vehicle manufacture.

Ensure 2 bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.

Fitted to 200 Series Toyota Land Cruisers—

The RP-NAV22 has an additional mount hole to make this item suitable for fitment to the 200 Series Land Cruiser. The 12mm Spacer Plates should not be required for the 200 Series fitment of these tow points.

The kits does NOT include the nuts required to secure the M12x1.25 bolts. You will have to provide these yourself if fitting to 200 Series Landcruiser.

RP-NAV22

Rated to
3250kgs per
tow point



Chassis Gusset for which 12mm Spacer Plates are required



12mm spacer



Ensure all supplied and specified components are used during the installation of these tow points. Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (3250kgs for Navara D22), which can result in serious injury or death.

Bolt Torque Specs

	8.8	10.9	12.9
M10	41-60 Nm	59-85 Nm	65-94 Nm
M12	71-105 Nm	102-150 Nm	114-164 Nm
M14	112-168 Nm	161-240 Nm	182-265 Nm
M16	175-260 Nm	250-371 Nm	282-406 Nm

Hardware supplied with RP-NAV22

- 4 x M12 x 1.25 Bolts
- 4 x M12 Flat Washers
- 4 x M12 Spring Washers
- 2 x 12mm Spacer Plates

RECOMMENDED FOR 4WD SPECIALISTS MECHANICS TO FIT