



Part Number—

SB004

Ranger/BT50 Shock Reinforcing Brackets

If you are upgrading your front shocks from original on Ford Ranger / Mazda BT-50 (Gen 1) then you will require Front Top Shock Support Reinforcing Brackets. The problem for cars without the bracket, with shock upgrades, is when out on the rough corrugated roads where the stronger shocks cause the original brackets to fatigue, leading to eventual breakage. Front Top Shock Support Reinforcing Brackets are designed to fit within (under) the existing shock mount, and provide support for the top shock mount, absorbing all the additional stresses applied due to increased shock rebound.

Installation

A hole is required to be drilled (for mounting bolts).

1. Remove the shock
2. Line up the shock mounting hole (for the shock pin)
3. Clamp the SB004 into place & mark the bolt hole location
4. Drill out the bolt hole
5. Put the SB004 into place & bolt up (making sure the shock pin hole aligns with the original shock mount plate)
6. Re-install the shock (repeat other side)

