

Nissan GQ & GU Patrol Offset Rubber Bushing Guide

Fitment of S0499R Offset rubber radius arm bushings, to increase caster. Bushings to be fitted to both passenger & drivers side, identical for both arms.

Lay the radius arm on this template & mark the bushing positions as indicated (for both arms).

Press the bushings in with the hole closest to the mark made above. Distance between hole centres is to be 240mm +/- 1mm for ease of fitment.

