

**VEHICLE** Isuzu D-Max / Mazda BT50 2020+

**PRODUCT** 10mm Diffdrop Kit

**PRODUCT CODE** DDDMAX20-10

**NOTE** Suggested fitment by a 4WD specialized mechanic

#### HARDWARE SUPPLIED:

- 2x M14 (P1.5) x 80L Bolts
- 2x Spring Washers
- 2x Flat washers

#### COMPONENT LIST:

- 2x Spacers

#### TOOLS REQUIRED:

- General Hand Tools

1. Raise vehicle and support securely.

2. Remove wheels and bash plates.

3. Support the front differential appropriately.

4. Undo the two bolts in **Figure 1**.

5. Lower the front differential and insert spacers above the bush as in **Figure 2**.

6. Fit supplied bolts and washers to the vehicle and tighten to the correct torque settings.

See **Figure 3**.

*Tip: Unbolting the rear crossmember and lowering the diff evenly can help align the front bolts.*

7. Check that the breather hose still reaches the breather outlet on top of the differential housing.

*Tip: If the breather hose no longer reaches the differential housing, a Blackhawk4x4 Diff Breather Kit can be used to connect the differential breather to the body hardline.*

8. Refit the bash plates and wheel and lower vehicle to the ground.

9. Torque wheel nuts to the factory specs.

