

FITTING INSTRUCTIONS

VEHICLE Any Tray Back Ute
MODEL YEAR Any
PRODUCT Auxiliary Battery Box
PRODUCT CODE BT008-A

Battery Tray Details
Fits up to N70zz 12-inch case battery.
Comes with: 2 x Backing Plates with welded threaded bolts & nuts and 4 x 6mm bolts, nuts and washers. As all trays are different thicknesses you may need to supply your own bolts.

- 1. Find desired position for battery tray. Place battery tray and mark to drill holes.
- 2. Drill four holes in the top of the tray. Place backing plates with welded 6mm threads through tray if suitable or use $4 \times 6mm$ bolts, nuts & washers and tighten.



3. Sit battery into box and place battery hold down on. Then tighten until battery is firmly in place.