

VEHICLE Toyota Land Cruiser 76 / 78 / 79 Series  
PRODUCT Bonnet Scoop Guard  
PART NUMBER BP103

TOOLS REQUIRED  
Body clip removal tool



1. Remove the plastic/rubber under bonnet duct.

2. Apply Sikaflex to inner folded faces of stainless guard.

3. Place guard on inside of bonnet scoop.

4. Scoop is not 100% straight: it dips away at the ends. Ensure the guard is parallel to the centre section of the scoop.

5. Have tape to hold things in place while the Sikaflex cures as per instructions.

6. Refit inner duct under bonnet once cured.

