

FITTING INSTRUCTIONS

NOTE

Ensure vehicle is on level ground.Chock front wheels to avoid vehicle rolling.

TOOLS REQUIRED TO COMPLETE FITMENT

12mm and 14mm socket

VEHICLE Nissan Navara NP300
PRODUCT Rear Locker Guard
PART NUMBER SB065

- 1. Remove the bolt holding the handbrake cable and (2) diff centre bolts. See figures 1 & 2.
- 2. Fit Blackhawk locker guard to vehicle.

 Ensure handbrake cable retaining bracket is on top of locker guard.

 See figure 2.
- 3. Fit all bolts and tighten.





