



# Brake Proportioning Valve Brackets

## Patrol GQ/GU & Cruiser 80/105

The Brake Proportioning Valve on the Patrols & Cruisers controls the amount of rear brake that is applied when you put your foot on the brake pedal. The higher you lift your vehicle the less brake is applied. The system itself is a great one, and ensures that if your vehicle is loaded or towing, and the back is lower, more rear brake is applied. To retain the standard brake bias on a lifted vehicle, Roadsafes have a simple bracket extension to reposition the Brake Proportioning Valve. Available to suit for 3", 4" & 5" lifts.



**BPV115** - suits for 3" lift

**BPV140** - suits for 4" lift

**BPV165** - suits for 5" lift

# Available Now!



VIC - Phone 1300 651 551 Fax 1300 651 451  
QLD - Phone 1300 559 086 Fax 1300 559 842