

TORQUE PACKER INSTALL

Insert torque packers into positions illustrated in the picture below.
One above and one below the OE rubber mount.
This is to limit axle wrap and movement of the axle tube.

