

JANUARY 19  
TAP112

## NEW PARTS REQUIRE GREASING

All products that are supplied with a grease nipple must be greased at installation. New parts that are fitted with a grease nipple only have a very small amount of assembly grease when manufactured. It is imperative that during the fitment of any greasable part adequate grease is installed via the grease nipple to ensure the products expected service life is maintained.

All greasable components are supplied with an accompanying note to advise that greasing upon installation & regular greasing is required.

*\*Failure to grease will result in a dramatically shorter lifespan not covered by manufacturer's warranty.*



Manufacturers Names used for reference purposes only.