

ROADsafe™



RP-NAV40

**Rated to
3250kgs per
tow point**

RP-NAV40 FITMENT GUIDE

Fitted to D40 Navara—

Fitted to factory retained nuts on L/H side
M12 x 1.25 Hi tensile Bolts and retained nuts supplied for R/H side

Ensure 2 bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.

2 bolts per side as supplied, can be mounted to front or rear of vehicle.



Fitted to 80" & 105" Toyota Land Cruisers—

105" Land Cruiser requires 4 x M12 x 1.25 bolts
100" Land Cruiser requires 4 x M14x 1.5 bolts
80" Land Cruiser requires 4 x M12 x 1.25 bolts

All models have nuts retained in chassis, ready for fitment, 2 bolts per side as supplied, can be mounted to front or rear of vehicle.

Ensure 2 bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.



Ensure all supplied and specified components are used during the installation of tow recovery points, Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (3250kgs for Navara D40), which can result in serious injury or death.

Bolt Torque Specs

	8.8	10.9	12.9
M10	41-60 Nm	59-85 Nm	65-94 Nm
M12	71-105 Nm	102-150 Nm	114-164 Nm
M14	112-168 Nm	161-240 Nm	182-265 Nm
M16	175-260 Nm	250-371 Nm	282-406 Nm

Hardware supplied with RP-NAV40

4 x M12 x 1.25 Bolts—Toyota Land Cruisers & Nissan Navara D40
2 x M12 x 1.25 Nuts on wires—Nissan Navara D40

RECOMMENDED FOR 4WD SPECIALISTS MECHANICS TO FIT